



Synergy 21 LED light panel Angel Wings V2 Ersatz Fernbedienung



kwh/1000h:	40,00
Lumens:	3200
Watt:	40,0
Nominal Service Life:	50000 Std.
Switching Cycles:	50000
Opt. Ambient Temperature.:	25 °C



Replacement remote control for Angel Wing V2

How to connect this remote control to the Angel Wing Panel 149407:

1. de-energise the Angel Wing panel.
2. switch the panel on again
3. within 10 seconds, please carry out the following:
Press the desired zone number (0-99) and the ID button
Press the desired zone number (0-99) and press the ID button
(it is very important that you carry out this step twice)
the panel will now flash once briefly.
4. de-energise the panel again (within the 10 seconds)
5. the login process is complete
6. switch the panel back on and operate it with the remote control

Additional Images

DIGITAL LIGHTING CONTROLLERS INSTRUCTION

Introduction of Multifunction Remote Controller & Simplified Remote Controller:

Power: Add battery(2). **Dimension:** 48x60x16. **Effective Distance:** 20M (Without Obstacle)

Number of controllable lamps: 1 controller can control 10 groups of lamps, and no limit to the number of lamps in one group.

ID of Lamp: 10 different codes for 1 to 10.

Multifunction: ON/OFF, Dimming and Color-temp adjusting setting ON/OFF, 2 scenes recall auto dimming, night light.

Copy the ID of Remote Controller: Every remote controller has its ID number. One controller can copy and save the ID number of another controller to control the same lamp, and receive its unique ID number.

Operating method:

Steps of setting ID number of lamps:

1) Turn OFF the lamp to which you want to set ID number, then turn on lamp. Mark step 1) within 15 seconds.

2) Press 1 or 2 numbers in the number key of remote controller, then press "COPY" key.

3) When you see ID light in lamp of remote, then the lamp will flash 1 time.

4) Turn off the lamp to which within 15 seconds, then flash setting.

Control the lamps:

The function of the keys on the picture on the right.

Control the single group: Press the ID number of the lamp you want to control and then press the function key (power, color temp, brightness).

All control mode press: "ON" key to control all groups.

TABLE: ON/OFF

Press the ID number of the lamp you want to set, press "COPY" key.

OFF: Press the number key 1-10, press "OFF" (holding ON key or "OFF")

holding OFF key, then flash setting, then turn on lamp.

Cancel: Press "OFF" key, then "OFF" (holding ON key or "OFF") holding OFF key to cancel setting mode.

COPY THE ID OF CONTROLLER:

Press "COPY" key of one controller and "ID" key of another controller

in the same time, and 6 seconds, the system will flash 3 times, then flash setting.

Memory: Press the "COPY" key and "ID" key of the controller which the ID has been copied for 6 seconds, the indicator will flash 3 times.

NIGHT LIGHT MODE:

Press "ON" key when the lamp is turned off by the controller to enter the night light mode.

CIRCLE MODE:

Press the ID of the lamp, then press "ON/OFF" (left, right, up, down) to enter the circle mode.

SCENE MODE: The system can save two scenes, "A" and "B".

Save:

1) Press the ID number of the lamp.

2) Press "A" or "B" key and then press "ON" or "OFF", the lamp will flash 1 time, then the scene will be saved.

Recall:

1) Press the ID number of the lamp.

2) Press "A" or "B" key, the lamp will enter the scene you preset.

