

Synergy 21 LED Controller EOS 08 KNX push-button 4-fold



- (1) 4 push keys
- (2) powered by KNX bus, 21-30VDC via EIB bus
- (3) for assignment of physical address

switching and dimming function
control of blinds and shutters
sending of values
recall and storage scene function
step-type switch function
setting the RTC operation mode
Multiple operation
LED indication function

Accessories

Part No.	Name
124108	Synergy 21 LED Controller EOS 08 KNX Dimmer 4*5A top hat rail
124110	Synergy 21 LED Controller EOS 08 KNX Dimmer 4*5A
124111	Synergy 21 LED Controller EOS 08 KNX Dimmer 4*350mA top hat rail
124112	Synergy 21 LED Controller EOS 08 KNX Dimmer 4*350mA

Part No.	Name
124113	Synergy 21 LED Controller EOS 08 KNX Dimmer 4*700mA top-hat rail
124114	Synergy 21 LED-Steuerung EOS 08 KNX Dimmer 4*700mA